


## NOTES:

- . FOR CONCRETE RAMPS, EXPANSION JOINT MATERIAL SHALL BE INSTALLED AT THE BACK OF THE CONCRETE CURB AND A BOND BREAKER AT THE SIDEWALK AND RAMP INTERFACE.
- FOR CONCRETE RAMPS A
  SAWCUT SHALL BE PLACED AT
  THE CENTRELINE OF THE
  DRIVEWAY RAMP AND EXTENDED
  THROUGH THE SIDEWALK AND
  CURB.
- 3. SAWCUTS SHALL BE PLACED IN THE SIDEWALK WHERE THE DRIVEWAY RAMP INTERSECTS THE SIDEWALK AND THE CURB AT TRANSITION.
- BOULEVARD SHALL BE RESTORED WITH MIN. 150mm OF SCREENED TOPSOIL AND NO. 1 NURSERY SOD, OR LOW-GROW SEED MIX AND FERTILIZER AS PER VOLUME 6 OF THE CITY OF WATERLOO COMPREHENSIVE DESIGN GUIDELINES & REQUIREMENTS (CDGR).
- PRIOR TO PLACEMENT OF SOD IN BOULEVARD, FERTILIZER (MIN. 0-25-0 TO 0-50-0 MAX.) SHALL BE APPLIED TO TOPSOIL AS PER MANUFACTURER'S APPLICATION RATE.
- DRIVEWAY TO BE A MINIMUM OF 1.2m FROM ANY STREET FURNITURE.
- 7. DEPRESSED CURB AND GUTTER AT DRIVEWAY ENTRANCES SHALL HAVE AN ADDITIONAL 50mm BENCH TO SUPPORT ADJACENT CONCRETE RAMPS, REFER TO OPSDE 600.040.



ALL DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE SHOWN.

STANDARD DRAWING

REV 1

**MAY 2023** 



