NOTES:

- 1. EXCAVATE AND CULTIVATE TO A DEPTH OF 600. IMPROVE STRUCTURE OF EXCAVATED SOIL BY AERATING,
- PULVERIZING, AND MIXING, REMOVING CLODS, LUMPS, AND DEBRIS (SUCH AS STONE, ROOTS, ETC.). BACKFILL USING IMPROVED NATIVE TOPSOIL.
- 3. SET CROWN OF ROOT BALL 25 ABOVE FINISHED GRADE OF PLANTING BED TO ALLOW FOR SETTLEMENT.
- 4. AFTER INSTALLATION OF PLANT MATERIAL, MULCH TO A DEPTH OF 100 (AFTER SETTLEMENT).
- 5. SOAK WITH WATER IMMEDIATELY AFTER INSTALLATION OF PLANT MATERIAL.
- 6. REMOVE ALL BROKEN, DISEASED, OR WEAK BRANCHES.
- 7. ALL SHRUB PLANT MATERIAL WILL BE PLANTED IN A COMPACT, MULCHED PLANTING BED.

ALL DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE SHOWN.

STANDARD DRAWING

REV 1

MAY 2023



CW-711

ALL DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE SHOWN

SHRUB / PERENNIAL PLANTING DETAIL

L